# CDP-14C

# 1 by 4 DisplayPort Splitter

**Operation Manual** 



#### Disclaimers

The information in this manual has been carefully checked and is believed to be accurate. Cypress Technology assumes no responsibility for any infringements of patents or other rights of third parties which may result from its use.

Cypress Technology assumes no responsibility for any inaccuracies that may be contained in this document. Cypress also makes no commitment to update or to keep current the information contained in this document.

Cypress Technology reserves the right to make improvements to this document and/or product at any time and without notice.

#### Copyright Notice

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means - electronic, mechanical, magnetic, optical, chemical, manual, or otherwise - without express written permission and consent from Cypress Technology.

© Copyright 2010 by Cypress Technology. All Rights Reserved. Version 1.0 December 2010

#### Trademark Acknowledgments

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

#### Safety Precautions

Please read all instructions before attempting to unpack or install or operate this equipment, and before connecting the power supply. Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- > To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through module openings or empty slots, as you may damage parts.
- > Do not attach the power supply cabling to building surfaces.
- > Do not allow anything to rest on the power cabling or allow it to be abused by persons walking on it.
- To protect the equipment from overheating, do not block the slots and openings in the module housing that provide ventilation.

#### Revision History

Version No	Date	Summary of Change
VR0	20110324	<b>Preliminary Release</b>

## **Table of Contents**

1.	Introduc	ction	1
2.	Applications1		
3.	Package Contents		
4.	System Requirements1		
5.	Feature	s	1
6.	Specifications2		
7.	Hardware Description3		
	7.1	Front Panel	3
	7.2	Rear Panel	3
8.	EDID Su	pport Format	4
	Connection and Installation		
10.	Acrony	ms	6

#### 1. Introduction

The DisplayPort (DP) 1 by 4 splitter allows single DP source to be display on four DP input monitors simultaneously. It supports video resolution up to 2560 x 1600 and audio up to PCM 7.1 switch provides a fast switch between source and display and save EDID's reading sink time to allow image display properly. The DP 1 by 4 splitter is an ideal device for your DP source to multi display.

#### 2. Applications

- Multi DisplayPort monitor display
- Information sharing
- Advertising program

#### 3. Package Contents

- 1 by 4 DisplayPort Splitter
- Operation Manual
- 5V/3 Power Adaptor

#### 4. System Requirements

- DisplayPort output source equipment.
- DisplayPort input monitors.

#### 5. Features

- Supports DisplayPort specification V1.1a
- Deep color video up to 12bit, resolution support up to 2560 x 1600
- Supports audio up to PCM 7.1(32-192kHz Fs sample rate)
- Supports pixel component formate with RGB; YCbCr 422; YCbCr 444
- Color sapce conversion between RGB and YCbCr color space
- Supports 1.62/2.7 Gbps data rate (Low/High bit rate)
- Supports flexible 1/2/4 lanes configurations; Full 10.8Gbps data ratesupport (4lanes at 2.7Gbps)
- Supports EDID switch and setting
  - \*Note: This device supports only DisplayPort mode, it cannot connect DP to HDMI level shift convert.

#### 6. Specifications

Frequency Bandwidth 10.8Gbps (4lanes at 2.7Gbps)

Audio Sampling Rate 192kHz

Input port 1 x Displayport

Output ports 4 x DisplayPort

Power Supply 5V / 3A DC (US/EU standards, CE/FCC/UL certified)

ESD Protection Human body model: ± 8kV (air-gap discharge)

± 4kV (contact discharge)

Dimensions (mm) 270(W) x 124.5(D) x 29(H)

Weight(g) 770

Chassis Material Aluminum

Silkscreen Color Black

Power Consumption 7W

Operating Temperature 0°C~40°C / 32°F ~ 104°F


Storage temperature  $-20^{\circ}\text{C} \sim 60^{\circ}\text{C} / -4^{\circ}\text{F} \sim 140^{\circ}\text{F}$ 

Relative Humidity 20~90% RH (non-condensing)

#### 7. Hardware Description


The following sections describe the hardware components of the unit.

#### 7.1 Front Panel



① Power LED: The LED will illuminate in green when power on and in red when in reset mode.

#### 7.2 Rear panel



- (1) EDID switch INT/EXT: This switch allows user to select the built-in EDID (INT) or the display's EDID (EXT).
  - Note: When the EDID switch is on EXT, the unit will detect OUTput 1's display EDID and record in the unit. If the first etected OUTput 1 is not connected, it will pass to the next which is OUTput 2...... and so on until the display's EDID is recoreded in the unit.
- ② RESET: Press this button every time when switch the EDID allowing the device to update the EDID selection.
- ③ DP OUT 1 ~ 4: These slots are where you connect the DP cable or DP to DP cable to your DP/DP input displayer for displaying a single source on two screens simultaneously.
- 4 DP IN: This slot is where you connect the DP cable from the source equipment for signal sending.
- (5) DC 5V: Plug the adaptor to the AC wallout for power supply to the device.

## 8. STD Mode EDID Support Format

Video Support		
VGA	•	
720p	•	
2560x1440	•	
Audio Support		
PCM 2CH 48K	•	
PCM 2CH 44.1K	•	
PCM 2CH 32K	•	

#### 9. Connection and Installation







Acronym Complete Term

EDID Extended Display identification Data

DP DisplayPort

